

DEVELOPMENTAL PLAYMAT WARNINGS AND INSTRUCTIONS

Please read all warnings and instructions before assembly and use. This packaging contains important information. Retain packaging and instructions for future reference.

Contents:

- Playmat
- 1 Canopy Structure
- 1 Tummy Time Caterpillar
- 1 Music and Lights Frog Mirror
- 9 Attachable Toys (Including 8 Links)

Assembly Instructions

- Carefully expand the canopy structure by unfastening the two closure straps. Canopy rods can spring outward when removed from packaging. Remove with caution.
- Position the canopy structure over the mat so that the four support bars line up with the loops on the perimeter of the mat.
- Use the straps on the end of each support bar to pass through and fasten around the loops on the perimeter of the mat. Canopy not intended for use without being connected to playmat.

Operating the Music and Lights Frog Mirror

- The frog mirror has three modes: Lights, music or sounds
- Use the switch located on the base of the mirror to switch the modes.
- To turn the frog mirror ON or OFF, use the frog's left forefinger. When pressed the frog will function in one of the 3 modes, specified by the switch on the base of the mirror. When the mode is finished (after 10 minutes), the mirror will turn OFF automatically.

Changing the Batteries in the Music and Lights Frog Mirror

- Locate the battery compartment door on the bottom of the mirror.
- Loosen the screw in the battery compartment door with a Phillips screwdriver.
- Remove the battery compartment door. Remove the old batteries and dispose of safely.
- Insert 3 AA alkaline batteries as indicated on the diagram inside the battery compartment door.
- Replace the battery compartment door and tighten the screw. Do not over-tighten.

Battery Tips

- Batteries should be replaced by adults.
- Do not mix old and new batteries.
- Do not mix different types of batteries: alkaline, standard (carbon-zinc) or rechargeable (nickel-cadmium batteries).
- Only 3 AA alkaline batteries (or equivalent) are to be used.

Por favor leer todas las advertencias e instrucciones antes de armar y utilizar. Este paquete contiene información importante. Conservar el paquete e instrucciones para referencia futura.

Contenido:

- Manta
- 1 Estructura de la Cubierta
- 1 Cabezal Oruga para el Momento de Barriga
- 1 Espejo Rana con Música y Luces
- 9 Juguetes para Ensamblar (Incluyendo 8 Eslabones)

Instrucciones para Armar

- Extienda cuidadosamente la estructura de la cubierta desatando las dos correas que sujetan. Las varillas de la cubierta pueden saltar hacia afuera cuando se las quita del embalaje. Quitar con precaución.
- Posicione la estructura de la cubierta sobre la manta de manera que las cuatro barras de soporte se alineen con los lazos en el perímetro de la manta.
- Utilice las correas en el borde de cada barra de soporte para pasarlas a través de cada lazo y atarlas alrededor en el perímetro de la manta. La estructura de la cubierta no fue diseñada para ser utilizada sin unir a la manta.

Como Operar el Espejo Rana con Música y Luces

- El espejo rana tiene tres modos: luces, música o sonidos
- Utilice la llave localizada en la base del espejo para cambiar los modos.
- Para Encender o Apagar (On-Off) el espejo rana, utilice el dedo índice izquierdo de la rana. Cuando lo presiona la rana funcionará en uno de los 3 modos, especificado por la llave en la base del espejo. Cuando se acaba el modo (luego de 10 minutos), el espejo se APAGARÁ automáticamente.

Como Reemplazar las Pilas del Espejo Rana con Música y Luces

- Localice en la parte baja del espejo la puerta del compartimento de pilas.
- Afloje el tornillo en la puerta del compartimento de pilas con un destornillador Phillips.
- Quite la puerta del compartimento de pilas. Quite las pilas viejas y descártelas de forma segura.
- Inserte 3 pilas alcalinas AA como se indica en el diagrama en el interior de la puerta del compartimento de pilas.
- Reubique la puerta del compartimento de pilas y ajuste el tornillo. No ajuste de más.

Consejos sobre las Pilas

- Las pilas deben ser reemplazadas por adultos.
- No mezcle pilas nuevas con nuevas.
- No mezcle diferentes tipos de pilas: alcalinas, estándar (carbón-zinc) o recargables (pilas de níquel-cadmio).
- Se deben usar solamente 3 pilas alcalinas AA (o equivalentes).

Sassy

© 2005 Sassy, Inc.
2305 Breton Industrial Park Drive S.E.
Kentwood, MI 49508
(616) 243-0767
www.sassybaby.com

Model #791
Made in China